




HP Compaq nc6400 Battery Replacement

A step-by-step replacement guide for the battery of an HP Compaq nc6400 Laptop.

Written By: Yoshitake Yamada




INTRODUCTION

This guide will take you through the process of replacing the battery in an HP Compaq nc6400 Laptop. You will need the correct replacement battery for your laptop to complete the installation.

Step 1 — Battery



 Make sure the laptop is turned off and unplugged.

Step 2



- Locate the battery lock below the battery labeled 1. Make sure to slide the lock all the way to the left to release the left lock of the battery

Step 3



- Once the left side of the battery is unlocked, locate the lock labeled 2 at the bottom right corner below the battery. Slide and hold the lock to the left, this will completely unlock the right battery lock

Step 4



- Once both the battery locks are unlocked, slide the battery out to remove.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 01:16:00 AM.